

Pneumatic Grip Accessories



Foot pedals

 $\underline{\text{None locking}} :$ The jaws of the grip open by pressing the foot pedal and close after removing the foot from the pedal.

Scope of delivery: 1 pair of foot switches including tubes and fittings



Foot pedals

<u>With locking function</u>: The jaws of the grip open by pressing the foot pedal and remain opened after removing the foot from the pedal. The jaws close by pressing the pedal one more time. Scope of delivery: 1 pair of foot switches including tubes and fittings



Pressure regulator

Optional for **Foot pedals**To adjust air pressure: 1-10 bar



Hand switches

With locking function: The jaws of the grip close by pulling the handle and remain closed. The jaws open by pushing the handle back.

Scope of delivery: 1 unit of hand switches including tubes and fittings



Micro hand switches

Pneumatic micro – hand switches, tubes and fittings, M5 connection With locking function: The hand switches are directly installed at the grips (only for 1/8" couplings), 3/2 directional valve. Only for single action rods with spring inside. Scope of supply: 2 hand switches including tubes and fittings



Compressor for laboratories, oil-lubricated

Max pressure 16 bar, 230 V, frequency 50 Hz, noise level: 38 dB (A)/1 m Displacement 5 l/min, tank size 3.1 l (0.82 gallon) Dimensions: 340x290x340 mm (L x W x H); weight 16 kg

Different voltages available on request